

Glass & Dishwasher

Hygiene & Maintenance

Daily

- Switch off power
- Remove basket
- Drain machine
- Remove filters
- Wash filters
- Wipe interior
- Top up chemicals
- Rinse out
- Leave door open

Additional Weekly

- Remove wash arms
- Strip and clean arms
- Wash machine internally with Renovater
- Regenerate water softener (if fitted)





5 simple steps to follow



Remove lemon slices and cocktail sticks or food scraps The machine is not a waste disposal unit



Manually remove lipstick The machine cannot do this automatically



Discard any drink residues into the sink The wash water is only refreshed between 10 & 20% each cycle



Do not wash or empty ashtrays into the machine



Do not interrupt or shorten the wash cycle To effectively clean & dry a full cycle is essential

Other tips for the maintenance of glasses

Renovate ALL glasses bi-monthly

Invisible detergent residues will damage a beer head.
Caustic detergents visually damage glasses.

Renovate all new glasses before use

New glasses are coated in a mould release agent and this will damage a beer.